

CHOOSING THE RIGHT SILICONE FOR NATURAL STONE

Natural stone, commonly used in kitchens, floors, walls, dining rooms and bathrooms, is a great choice for many reasons. Ensuring you choose the correct silicone for your intended use is critical in preventing damage to the material's surface.

Staining of natural stone is common during caulking of edges. It occurs because oils and liquids within the silicone formula penetrate the stone during application, resulting in irreversible damage. This appears as a dark 'wet-looking' stain on both sides of the joint where the silicone has been applied. However, there are solutions to prevent this, introducing Maxisil Natural Stone.

Unlike other sealants, Maxisil Natural Stone is specifically designed with in-built fungicides to fight mould and guaranteed not to stain stone.

Trusted for over 23 years by professionals, Maxisil Natural Stone was developed with harsh conditions in mind. It's easy to use and UV stable.





WHERE MAXISIL N CAN BE USED

This sealant is incredibly versatile and ideal for a wide array of applications, including:

- · Marble / Granite benchtops
- · Stone flooring
- Pavers
- Facades
- · Expansion joints

DON'T BE CONFINED BY LIMITED COLOUR OPTIONS!

Maxisil Natural Stone is available in over 20 colours, enabling you to match your sealant with any surface or colour scheme.

We even have a matte finish range of colours, ensuring you get the desired look and finish.

To ensure you get a professional finish every time, follow the Maxisil system!

HERE IS OUR EASY GUIDE TO GETTING A PROFESSIONAL FINISH





9

REMOVE as much of the old silicone as possible (if required).

2



CLEAN the joint before

cotton cloth.

applying silicone with **Maxisil Cleaner** (airing time approx. 1 minute) using a clean, lint-free

(3



CAULK

Apply Maxisil Natural Stone silicone using a caulking gun or similar.

4



APPLY

Apply Maxisil Smoothing Agent (Smoothtex N) in a spray bottle or brush. Use an applicator to finish the joint area look and shape to get a professional finish every time.

PRODUCT:



RDX2004 MAXISIL CLEANER



RDX1001* MAXISIL Natural Stone

*Over 20 colours to select from



RDX2019 MAXISIL SMOOTHTEX N

TIPS & TRICKS



Allow your silicone to cure for at least 72 hours before using the area where silicone has been applied.



Hold and use the applicator at different angles when smoothing out the silicone to achieve the desired joint size.

For more information on Maxisil Natrual Stone and to see the full range of Maxisil products, visit maxisil.com

